

Установи "Splice+"



Splice+ это приложение для смартфона, предназначенное для работы с термострипперами серий RS02/RS03, оснащенных функцией Bluetooth. Приложение позволяет изменять настройки термострипперов, обновлять прошивку, включает руководства пользователя и т.д. **Splice+** доступен бесплатно на Google Play.

google play fujikura splice+



Инструкции по запуску

При запуске, приложение отображает список доступных устройств и устройств, подключаемых ранее.

В левой части основного меню располагаются квадратные иконки

+ Синий цвет иконки – устройство не подключено. При нажатии, происходит подключение устройства.


+ Голубой цвет иконки – устройство подключено.

+ Серый цвет иконки – устройство не готово к подключению. В этом случае доступен просмотр данных устройства, полученных при последнем соединении.

Для подключения устройства, не отображаемого в списке или чья иконка серая, нажмите кнопку Bluetooth на устройстве до тех пор, пока световой индикатор Bluetooth не начнет мигать.

Когда световой индикатор Bluetooth начнет мигать, устройство отобразится в списке приложения синей иконкой. Теперь подключите устройство нажатием на иконку.

* Splice+ будет доступен для iPhone в середине июля 2017.



Ниже приведено описание функции Splice + .

The screenshots illustrate the following steps in the application:

- Device Settings:** Shows device information for RS03 (#000010), Ver 01.01d. STATUS includes Battery (90%) and Usage Counter (102/100000). SETTINGS include Heat Temperature Level (1-4), Finish Time (3 Secs), ECO/Preheat Mode (ECO/Preheat), Shutdown Time (10 Mins), Heating Time (10 Secs), and Buzzer Volume (2).
- Log:** Shows a bar chart for RS03 (#000010) with a date of Jul.4 2017 TODAY.
- Main Menu:** Options include 'Create a heating recipe', 'Apply a preset recipe', 'Clean heater and blades', and 'Contact your distributor'.
- Firmware Update:** Shows 'LATEST FIRMWARE ON THE SERVER' with Version 01.01d, Date 2017-06-07, and Size 194 KB.
- Tutorial:** Lists steps: How to operate, Cleaning, Heat temperature setting, Operation mode setting, Battery, Stripping length changing, and Bluetooth connection.
- How to operate:** Includes an image of the device and text: 'Place a fiber into an appropriate fiber holder. Slide the holder clamping unit to the main body and place the fiber holder into the holder clamping unit. Confirm the fiber edge is within yellow area.'
- Create a New Heating Recipe:** Fields for 'Heating Recipe Title' (No Title), 'Heat Temperature Level' (1 to 4), and 'Standard Finish Time' (1 to 60 seconds, set to 3).
- Contact Distributor Information:** Fields for 'Phone Number (Local)' (442082402000), 'Name' (Fujikura Europe Ltd.), 'Phone Number (Intn. / Long Distance)' (+ 44-2082402000), and 'E-Mail'.
- Cleaning:** Includes an image and text: 'Turn off the power of the RS and then pull the holder clamping unit. Open the main body lid and clean the both upper and lower blades, heater plate and rubber using the brush or an alcohol-moistened cotton swab.'

Место Следующее
нажатия изображение